

Place the kite face down. There are 3 loose spars; 2 medium and 1 long. Make sure the center spine is already pre-assembled. If it is not, first insert the long center spar into the pockets located at the top and bottom of the kite. Insert the two medium spars into the pockets in the top set of legs and the bottom set (see illustration). Insert the longest spar into the pockets of the center set of legs. Attach line to the tow point and fly.

---

